



Handlebars switch (right)

"HAZARD" switch		"START" switch		"ENGINE STOP" switch	
OFF	ON	OFF	ON	OFF	RUN
Br/W	Br/W	R/Y	L/B	R/W	R/W
Dg	Ch	L/W	B	B	B
Br/Y	Ch	B	B	B	B

Front flasher light (left)

Front flasher light (right)

Meter ass'y

Tachometer

METER

METER

HEAD LAMP

HIGH BEAM

NEUTRAL

WARNING

TURN x 2

Computerized monitor

STND

BRK

OIL

BATT

HEAD

TAIL

FUEL

Headlight

Sender

Meter light

Main switch

OFF	ON	PI	PII
R/Y	R	Br	L
W/R	W/R	W/R	W/R

* The key can be removed in this position

Horn

Horn

"LIGHTS" (Dimmer) switch

HI	LO
Y	L/B
G	G

"TURN" switch

OFF	ON
P	B
Ch	Br/W
Dg	Ch
Y/R	B
L	L
L	L

"HORN" switch

OFF	ON
P	B
Ch	Br/W
Dg	Ch
Y/R	B
L	L
L	L

Handlebar switch (left)

Fuse box

TAIL 10A
HEAD 10A
SIGNAL 20A
IGNITION 10A

Rear flasher light (left)

Tail/Brake light

Rear flasher light (right)

Flasher cancelling unit

Battery

Starter relay

Stator motor

Oil level switch

Rear brake switch

Battery sensor

Sidestand relay

Flasher relay

Hazard relay

Clutch switch

Ignition coil (left)

Rectifier regulator

Field coil

Stator coil

Brake fluid switch